

## NEULOG FLOW LOGGER SENSOR GUIDE



### NeuLog flow logger sensor NUL-224

The NeuLog flow sensor can be used for any science experiment which involves a liquid flow rate such as in the fields of Environmental Science, Ecology, Earth Science, Biology, Chemistry, Physics, etc.

The sensor comes pre-calibrated so you can start experimentation right out of the box using this guide.

Among hundreds of possible experimental subjects that can be studied with the NUL-224 sensor are: stream velocity and health, turbidity, density versus flow rate, fluid pressure and flow relationships, and many more.

The flow sensor's measurement unit is:

- Meters per second (m/s): The SI unit of liquid flow rate.

### Connecting to the flow sensor:

The flow sensor takes measurements of liquids flowing through the flow probe attachment. There are a few options for connecting the probe attachment to a water source:

- directly to a faucet using the threaded inlet and outlet pipes
- connecting the inlet and outlet pipes to the sample being tested through the rubber hosing
- connecting the probe to a ruler and submerging it directly into water (a river for instance) to take flow measurements.

Please note that our flow logger sensor is meant to be used for liquids and not air.

### Quick start procedure:

#### PC or Mac Computer

#### Materials needed:

- NUL-224 Flow Sensor
- USB-200 USB Module
- USB to mini USB cable (included with the USB-200 module)

Your flow sensor needs to be connected to a USB-200 module. The USB-200 module then connects to a computer via a USB to mini-USB cable. Please note that you cannot plug the flow sensor directly into the computer.

The browser based application can be downloaded for free at [www.NeuLog.com](http://www.NeuLog.com) as well as a full application user guide. Choose "Downloads" on the main menu and then choose "Software and Application".

#### Procedure:

1. Install the NeuLog application.
2. Connect the USB-200 module to the PC or Mac.
3. Connect the flow sensor to the USB-200 module (they directly plug together). Please note that no calibration is required for this sensor.
4. Open the NeuLog application by clicking on the shortcut on the screen.
5. Once a flow sensor module box appears on the left side of the screen the probe has been automatically identified and you can begin experimentation.
6. If the flow sensor is not automatically identified then click the "Search for sensors" icon to find the sensor.
7. Click on the "On-line experiment" icon; this will open a graph below.
8. Click on the "Module setup" button located in the flow sensor module box to change the sensor's settings if need be.
9. Click on the "Experiment setup" icon to change the experiment settings if need be (experiment duration for example).
10. The flow sensor will give a live reading in the module box to the left of the screen while plugged in.
11. To run an experiment and collect data click the "Run experiment" icon.
12. To end data collection early, click the "Stop experiment" icon.

## NEULOG FLOW LOGGER SENSOR GUIDE



### Tablet, smart phone device

#### Materials needed:

- NUL-224 Flow Sensor
- WIFI-201 WIFI Module
- BAT-200 Battery Module

Your flow sensor needs to be connected to a WIFI-201 module. The WIFI-201 module will create a closed NeuLog WiFi network which will stream the NeuLog data to a device of your choosing. Once your device is wirelessly connected to the NeuLog network, you can run experiments and collect data through a browser of your choosing.

#### Procedure:

1. Connect the flow sensor directly to the left side of a WIFI-201 (no wires required).
2. Connect a BAT-200 module to the right side of the WIFI-201 module.
3. Although not required, we recommend plugging the BAT-200 to an outlet using a USB to mini USB charger (such as a typical cell phone charger). The WIFI-201 module will run for 60-90 minutes (depending on the sensor) without being plugged in.
4. The WIFI-201 can be powered directly using a mini to USB cord and plugging it into your computer or a wall charger. Please note this function is only available on WIFI-201 modules with the USB icon on the cover.
5. For further WIFI-201 instructions or the WIFI-201 quick start guide please visit: [www.NeuLog.com](http://www.NeuLog.com); Choose "Products" on the main menu, then choose "WiFi Communication module".
6. The WIFI-201 indicator lights will flash; take no action until the LED to the far left turns blue; this can take up to one minute.
7. Take your tablet or smart phone, go to the WiFi settings and select the NeuLog network (NeuLog0184 for example) which matches the ID found on the back of the WIFI-201 module (0184 for example).
8. Give your device about 20 seconds to connect to the WIFI-201.
9. Once the device is connected, go to your browser and type the website **wifi201.com** into the URL bar, then wait for 30-60 seconds.
10. You will see a "Control mode" icon in the application, click on it.
11. The application will then load a new screen and begin to auto detect the sensor(s); this can take a minute. (You can stop the search when the sensor is found.)

12. If the application does not auto detect the sensor(s), select "Search for sensors".
13. Once the sensor is found you will see a module box on the left side of the screen for the flow sensor. In this box, real time data will be displayed.
14. Click on the "Module setup" button located in the flow sensor module box to change the flow probe settings if need be.
15. Click on the "Experiment setup" icon to change the experiment settings if need be (Experiment duration for example).
16. To run an experiment and collect data, click the "On-Line experiment" icon, then click the "Run experiment" icon.
17. If you have a newer generation WIFI-201 (with the USB icon on the cover) this can be used as a USB-200, meaning you can tether the probes directly to the computer using the WIFI-201. To engage operation in this fashion, press 3 times on the panel button. Repeating this operation will return the module to WiFi mode.

### Operation with NeuLog Graphic Display Module (viewer)

#### Materials needed:

- NUL-224 Flow Sensor
- VIEW-101 Graphic Display Module
- BAT-200 Battery Module

#### Procedure:

1. Connect the flow sensor to the left side of the viewer.
2. Connect the BAT-200 module to the right side of the viewer.
3. The VIEW-101 will auto detect the sensor and you will see it appear on the left side of the screen.
4. Once the sensor appears it will be monitoring data in real time.
5. To run an experiment and collect data press the run icon (little green person).

### Off-line experiments

(Off-line experiments are when you do not have a sensor connected directly to a computer, tablet, smartphone, or NeuLog viewer).

#### Materials needed:

- NUL-224 Flow Sensor
- BAT-200 Battery Module

## NEULOG FLOW LOGGER SENSOR GUIDE



### Materials needed to configure your offline experiment:

- USB-200 Module, WIFI-201 Module or VIEW-101 Module
- USB to mini USB cable (included with the USB-200 module)

### Procedure:

1. To determine the experiment settings, first connect to your chosen device (PC, Mac, tablet, smart device) and click on the "Off-line experiment" icon after the sensor search has ended. (For more information on how to change the experiment settings, view the quick start procedure section for your chosen device in this document.)
2. Connect the flow sensor directly to the left side of a charged BAT-200 module.
3. When ready to collect data press the "Start/Stop" button on the flow sensor; a red light will turn on for the duration of the experiment.
4. After the experiment has concluded (the "Start/Stop" button is pressed again or the data collection period ends) connect the sensor to your chosen device (you can find full instructions in each device's quick start procedure section).
5. Open the NeuLog application.
6. Click the "Off-line experiment" icon.
7. Click the "Load data from sensors" icon.
8. Select which experimental data to upload (5 experimental runs can be stored at one time on the NUL-224 flow sensor).

### Restoring sensor's factory default settings:

#### Procedure:

1. Connect the USB-200 to a PC, Mac, tablet, or smart device.
2. Connect the flow sensor to a USB-200 module (they directly plug together).
3. Open the NeuLog application.
4. Click the "Tools" icon.
5. Click "Restore sensor's factory defaults" on the menu.

### Included with the sensor:

- NeuLog NUL-224 Flow Sensor Guide (this document)
- Flow sensor probe attached directly to the sensor's body by a durable rubber-coated wire

### Sensor's specifications

<b>Range and operation modes</b>	0 to 5 m/s
<b>ADC resolution</b>	Digital
<b>Resolution</b>	0.08 m/s
<b>Max sample rate (S/sec)</b>	100

**Experiment Duration:** 1 second to 31 days.

### Sensor's features:

- Fully digital data
- Rugged plastic ergonomic case
- Flow rate probe attached to the sensor's body by a durable rubber-coated wire
- Push button switch for Start/Stop experiments in off line mode
- LED indicator of experiment status (blinks while collecting data)
- Pre-calibrated sensing equipment

**Note:** NeuLog products are intended for educational use.

### Videos and experiment examples:

- Videos, literature and other probes can be found at [www.NeuLog.com](http://www.NeuLog.com).
- In order to access the flow sensor's page, choose "Products" on the main menu and then "Flow logger sensor".
- In order to find the science experiments, choose "Experiments" on the main menu of the NeuLog website, then choose "Physics", "Chemistry", "Biology" or "Environmental Science".
- Physics Experiment:
  - Flowing Water (P-43)

## NEULOG FLOW LOGGER SENSOR GUIDE



### Technical background:

The philosophy behind NeuLog's plug and play technology is based on each sensor's ability to store its own data due to an internal flash memory chip and micro-controller in each plastic NeuLog body. This technology allows the sensor to collect and then store the digital data in the correct scientific units (oC, oF, Lux, %, ppm, for example).

The sensor is pre-calibrated at the factory. The built-in software in the logger can be upgraded for free at any time using the provided firmware update.

The flow sensor houses an internal water wheel; as liquid flows through the probe the wheel rotates at the same velocity as the liquid's. The water wheel does not connect directly to the walls of the sensor but instead, floats on a bearing to lower the friction of the system allowing for the water wheel to take the velocity of the water passing through it more accurately.

The water wheel shaft includes a magnet and the rotation is sensed by a Hall Effect sensor, without any mechanical connection.

The flow is calculated by the internal controller that converts the rotation speed into flow rate.

### Maintenance and storage:

- Never submerge the NeuLog sensor's plastic body in any liquid.
- Do not allow liquid into the flow sensor's body.
- After use, gently wipe away any foreign material from the flow sensor.
- Store in a box at room temperature out of direct sunlight.

### Warranty:

We promise to deliver our sensor free of defects in materials and workmanship. The warranty is for a period of 3 years from the date of purchase and does not cover damage of the product caused by improper use, abuse, or incorrect storage. Sensors with a shelf life such as ion selective probes have a warranty of 1 year. Should you need to act upon the warranty, please contact your distributor. Your sensor will be repaired or replaced.

Thank you for using NeuLog!



Flexible, simple, fast, forward thinking.

W: [www.neulog.com](http://www.neulog.com)

E: [info@neulog.com](mailto:info@neulog.com)

A: 850 St Paul Street, Suite 15, Rochester, NY 14605

P: 1.866.553.8536

V11042014